

Glen Brittle Memorial Hut

Instructions for filling and draining water at the hut in winter .

Water heater above kitchen sink and immersion heater in entrance hall and at the hot water cylinder in the drying room should not be switched on until the system has filled

To FILL the system

1. Close the blue valve outside South gable of hut.
2. Close main drain valve (above and to left of inlet valve in SW corner of drying room).
3. Close all 12 taps (2 in drying room, 2 in ladies, 4 in gents, 4 in kitchen).
4. Close drain valve below gents shower.

To DRAIN the system.

1. Switch off water heater above kitchen sink.
2. Switch off immersion water heater, both in entrance hall and at the hot water cylinder in drying room.
3. Open the blue valve outside South gable of hut.
4. Close inlet valve in SW corner of drying room.
5. Open drain valve (above and to left of of inlet valve).
6. Open all 12 taps (2 in drying room, 2 in ladies, 4 in gents, 4 in kitchen).
7. Open drain valve below gents shower.
8. Flush all toilets.